



## GRB263 Rocker Switch Parts List

( ) = Momentary

| Item #                           | Circuitry | Switch Function | Electrical Rating                                      | Actuator Style/Color                   | Terminal Style     | Waterproof & Dust Proof | Lamp Type                               | Printing      |
|----------------------------------|-----------|-----------------|--|--|--------------------|-------------------------|---|---------------|
| <a href="#">GRB263A0BBNN</a>     | SPST      | ON-OFF          | 16(4)A 125/250VAC<br>20A 250VAC<br>21A 14VDC/ 10A28VDC | Standard/Black                         | .250 Quick Connect | IP56                    | None                                    | None          |
| <a href="#">GRB263A001BBNN73</a> | SPST      | ON-OFF          | 16(4)A 125/250VAC<br>20A 250VAC<br>21A 14VDC/ 10A28VDC | Standard/Black                         | .250 Quick Connect | IP56                    | None                                    | I/O- In White |
| <a href="#">GRB263A101RN1D</a>   | SPST      | ON-ON           | 21A 14VDC  | Standard/Black-<br>Red Lens            | .250 Quick Connect | IP56                    | 14 Volt Red LED<br>Dependent            | None          |
| <a href="#">GRB263C001NNN</a>    | DPDT      | ON-ON           | 16(4)A 125/250VAC<br>20A 250VAC<br>21A 14VDC/ 10A28VDC | Standard/Black                         | .250 Quick Connect | IP56                    | None                                    | None          |
| <a href="#">GRB263D001NNN</a>    | SPDT      | ON-OFF-ON       | 16(4)A 125/250VAC<br>20A 250VAC<br>21A 14VDC/ 10A28VDC | Standard/Black                         | .250 Quick Connect | IP56                    | None                                    | None          |
| <a href="#">GRB263D2BBGR2D1</a>  | SPDT      | ON-OFF-ON       | 21A 14VDC  | Standard/Black-<br>Red & Green<br>Lens | .250 Quick Connect | IP56                    | 14 Volt Red &<br>Green LED<br>Dependent | None          |